*** OmniDisk ***

Aerco Disk Conversion Program for Omnicalc II

If you want to use a full size printer with Omnicalc, prepare the driver software in one of the following ways:

<1> For printer drivers to be loaded above address 64256, load the driver now and get it ready to print. You will not need to load the printer driver again to use Omnicalc.

<2> For printer drivers to be loaded in the printer buffer (between 23296 and 23552), you have to load the driver each time before you load Omnicalc.

Note: Because of the additional disk routines, this program converts only Omnicalc II, version 64000.

After loading the appropriate printer driver, load the conversion program by: **CAT "OmniDisk.BAS",**
Then play the Omnicalc II cassette. The program will automatically find the correct version.

After Omnicalc II is loaded, you can customize the program by changing the values in the "menu". Use keys "6" and "7" to move the cursor to desired location and "ENTER" to change that item. The length of the error buzz can be any number between 0 and 7 inclusive. If you do not have a full size printer or printer driver which supports high resolution screen dump, leave the screen copy address as 2562. After you are finished, press "0" to exit the conversion program.

Then a program loader will prompt you to type a filename for the converted Omnicalc II. The name can be up to 10 characters long and should not contain any period "." Two disk files will be generated with names "name.BAS" and "name.BIN".

To load the converted Omnicalc II, type in the command:
CAT "name.BAS",
Omnicalc II will start running after it is loaded. Now normal save and load commands will access disk files. To save to or load from cassette, precede filename with "*". To see the disk directory, use "?" as the first character of filename in either save or load mode. You may also add a drive specification (A-D) after "?" to access more than one drive.

Note: Ignore any verify options by pressing "N".

If you have any questions or suggestions about OmniDisk, please send them to:

Chia-Chi Chao
73 Sullivan Drive
Moraga, Ca. 94556

If you need reply, please enclose a SASE.

Transfering OmniDisk from tape to disk

1. Insert a disk into drive A. If you are using a disk with an auto-boot program on it (BOOT.BAS), skip step 2.

2. LOAD "1" ------ Stop Tape -- RUN 9999

3. LOAD "2" ------ Stop Tape -- RUN 9999

4. LOAD "3"CODE -- Stop Tape -- MOVE "OmniRead.BIN",32500,89

5. LOAD "4"CODE -- Stop Tape -- MOVE "OmniExtent.BIN",64000,249

6. LOAD "5" ------ Stop Tape -- RUN 9999

7. Refer to the OmniDisk documentation for actual conversion.